

		Engine Oil Filter	Hyd Oil Filter	Fuel Filter	Air Single	Air Outer	Air Inner
Model	Engine						
SL3310 Prior sn 1501	B48G Onan	611990	076030	088360	075986		
SL3310 After sn 1501	P220 Onan	088361	076030	088360	075986		
SL3410	QT23 Isuzu 3 cylinder	122497	076030	078856	079388		
SL3510 Prior sn 1922	I-67 Ford (KSG)	078852	073479	078851	055017		
SL3510 After sn 1921 & prior 2420	I-67 Ford (KSG)	078852	076030	078851	055017		
SL3510 After sn 2419 & prior 3502	I-67 Ford (VSG)	083715	076030	078851	079388		
SL3510 After sn 3501	I-67 Ford (VSG)	083715	076030	089314	079388		
SL3515 Prior sn 6702	I-67 Ford (VSG)	083715	076030	078851	079388		
SL3515 After sn 6701	I-67 Ford (VSG)	083715	076030	089314	079388		
SL3610 Prior sn 1655	QD27 Isuzu 2 cylinder	078854	073479	078853	055017		
SL3610 After sn 1654 & prior 2001	QD27 Isuzu 2 cylinder	122497	076030	078853	055017		
SL3610 After sn 2000	QT35 Isuzu 3 cylinder	122497	076030	078856	079388		
SL3615	QT35 Isuzu 3 cylinder	122497	076030	078856	121839		
SL3725	Ford VSG-411	083715	115259	089314	055017	092397 if applicable	092398 if applicable
SL3825, SL3825SX Prior sn 8311	Kubota V1305-B	121433	115259	114868	055017	092397 if applicable	092398 if applicable
SL3825, SL3825SX After sn 8310	Kubota V1305-B	121433	115259	123828	055017	092397 if applicable	092398 if applicable
SL4510 Prior sn 5501	I-98 Ford (KSG)	078852	074830	078851	055017	092397 if applicable	092398 if applicable
SL4510 After sn 5500	I-79 Ford (VSG)	083715	074830	089314	055017	092397 if applicable	092398 if applicable

SL4515 Prior sn 6131	1-98 Ford (KSG)	078852	074830	078851	055017	092397 if applicable	092398 if applicable
SL4725	Ford VSG-413	083715	115259	089314	055017	092397 if applicable	092398 if applicable
SL4610 Prior sn 8501	4-108 Perkins Dsl	078849	074830	078850	055017	092397 if applicable	092398 if applicable
SL4610 After sn 8500	100 Series Perkins	078849	074830	113890	055017	092397 if applicable	092398 if applicable
SL4615 Prior sn 14201	4-108 Perkins Dsl	078849	074830	078850	055017	092397 if applicable	092398 if applicable
SL4615 After sn 14200	100 Series Perkins	078849	074830	113890		092397	092398
SL4625, SX & DX Prior sn 16852	Kubota V2203-B	121965	115259	114868	055017	092397 if applicable	092398 if applicable
SL4625, SX & DX After sn 16851 & Prior 17248	Kubota V2203-B	121965	115259	123828	055017	092397 if applicable	092398 if applicable
SL4625, SX & DX After sn 17247	Kubota V2203-B	121965	074830	123828	055017	092397 if applicable	092398 if applicable
SL5620	4-154 Perkins	079756	074830	079757	078934	087860 if applicable	087859 if applicable
SL5625, SX & DX Prior sn 8868	4-154 Perkins	079756	074830	079757		087860	087859
SL5625, SX & DX After sn 8867	204.25 Perkins	127389	074830	079575		087860	087859
SL6620/6625 Prior sn 7605	4-154 Perkins	079756	074830	079757	078934	087860 if applicable	087859 if applicable
SL6625, SX & DX After sn 7604	204.30 Perkins	127389	074830	079757		087860	087859
HL360	B43M Onan		048959	600449	603913		
HL2600 Prior sn 1188	NHC Onan	600287	061511		063733		
HL2600 After sn 1189	NHC Onan	600287	061511		055017		
HL4300	VH4D Wisconsin	055916	Cartridge or Spin-on		055017		
HL4500	1-98 Ford	078852	Cartridge or Spin-on	078851	055017		
HL4600	4-108 Perkins Dsl	078849	Cartridge or Spin-on	078850	055017		